


Entry Light Control System

Rear Ceiling Light Test/Replacement

1. Turn the front ceiling light switch OFF.
2. Pry off the lens.



3. Remove the two bolts and the housing.
4. Disconnect the 2-P connector from the housing.

5. There should be continuity between the A and B terminals with a bulb installed.

