

Power Mirrors

Power Mirror Replacement

NOTE: Before removing the mirror, raise the window fully.

1. Remove the door panel (see [section 20](#)), and all connectors.
2. Disconnect the 8-P connector from the mirror.
3. While holding the mirror with one hand, remove its mounting nuts with the other.

