


# Wipers/Washers

## Component Location Index

### CAUTION:

- ALL SRS wiring harnesses are covered with yellow outer insulation.
- Before disconnecting any part of the SRS wire harness, install the short connectors (see page 23-409).
- Replace the entire affected SRS harness assembly if it has an open circuit or damaged wiring.



**SRS MAIN HARNESS**  
(Covered with yellow outer insulation)

