

# Power Front Passenger's Seat

## Power Seat Switch Test

**CAUTION:** Be careful not to damage the seat, the interior trim or the body.

- 1. Remove the front passenger's seat, then remove the power seat switch.
- 2. Check for continuity between the terminals in each switch position according to the table.

Terminal		A	B	C	D	E	F	G	H	I	J	K	L	M	N	O	P	Q	R
Position																			
SLIDE	FORWARD		○							○									
	NEUTRAL		○	○			○												
	BACKWARD		○							○									
RECLINE	FORWARD				○						○			○					
	NEUTRAL				○	○								○					
	BACKWARD				○	○						○		○					

