

Clutch

Special Tools	12-2
Description (6-Speed)	
Dual Mass Flywheel	12-3
Illustrated Index	12-4
Clutch Pedal	
Adjustment	12-5
Clutch Master Cylinder	
Removal	12-6
Installation	12-6
Slave Cylinder	
Removal	12-7
Installation	12-7

Pressure Plate, Clutch Disc	
Removal	12-8
Pressure Plate	
Inspection	12-8
Clutch Disc	
Inspection	12-9
Release Bearing	
Inspection	12-10
Flywheel, Ball Bearing	
Inspection	12-10
Replacement	12-11
Pressure Plate, Clutch Disc	
Installation	12-12