

## Differential

Special Tools .....	15-2
Troubleshooting .....	15-3
Maintenance	
Differential Oil .....	15-4
Differential Assembly	
Removal/Installation .....	15-5

Deletion of Secondary Cover	
('95 Model) .....	15-2
Component Location Index .....	15-7
Inspection .....	15-8
Disassembly .....	15-10
Reassembly .....	15-15

Differential Carrier	
Inspection .....	15-14
Drive Pinion	
Height Adjustment .....	15-23
Ring Gear Tooth Contact	
Adjustment .....	15-24
Ring Gear Backlash Adjustment ...	15-24