

# Suspension

Special Tools .....	18-2
Component Location Index .....	18-3
Wheel Alignment	
Caster .....	18-4
Camber .....	18-4
Front Toe Inspection/ Adjustment .....	18-5
Rear Toe Inspection/ Adjustment .....	18-5
Turning Angle Inspection .....	18-6
Wheel Measurements	
Bearing End Play .....	18-7
Runout .....	18-7

Front Suspension	
Torque Specification .....	18-8
Illustrated Index .....	18-9
Knuckle/Hub Replacement .....	18-10
Ball Joint Boot Replacement .....	18-16
Front Damper	
Removal .....	18-17
Disassembly/Inspection .....	18-17
Inspection .....	18-18
Reassembly .....	18-19
Installation .....	18-19

Rear Suspension	
Torque Specification .....	18-20
Hub Bearing Unit	
Replacement .....	18-21
Illustrated Index .....	18-24
Knuckle/ Upper Arm/Lower Arm/ Radius Rod Removal .....	18-25
Ball Joint Boot Replacement .....	18-28
Rear Damper	
Removal .....	18-28
Disassembly/Inspection .....	18-29
Inspection .....	18-30
Reassembly .....	18-31
Installation .....	18-31