

Brakes

*: Read [SRS precautions](#) before working in this area

ABS (Anti-lock Brake System)

Special Tools	19-2
Illustrated Index	19-3
Pedal Height	
Adjustment	19-4
Parking Brake	
Inspection/Adjustment ...	19-4
Front Brakes	
Index/Inspection	19-6
Front Brake Pads	
Inspection/Replacement .	19-7
Front Caliper	
Disassembly	19-9
Reassembly	19-10
Front Brake Disc	
Runout Inspection	19-10
Thickness and Parallelism	
Inspection	19-10
Bleeding	19-11
Master Cylinder and Brake Booster	
Index/Torque	19-13
Master Cylinder	
Inspection	19-14

Brake Booster	
Tests	19-15
Pushrod Clearance	
Adjustment	19-16
Rear Brakes	
Torque/Inspection	19-17
Rear Brake Pads	
Inspection/Replacement .	19-18
Parking Drum Brakes	
Index	19-21
Inspection	19-22
Disassembly	19-23
Lining Surface Break-in .	19-25
Rear Caliper	
Disassembly/Reassembly	19-26
Rear Brake Disc	
Runout Inspection	19-28
Thickness and Parallelism	
Inspection	19-28

Brake Hoses/Pipes	
Inspection	19-29
*Parking Brake Cable	
Disassembly/Assembly ..	19-30
Anti-lock Brake System (ABS)	
Features/Construction/	
Operation	19-31
Circuit Diagram	19-44
Wiring/Connector Locations .	19-46
ALB Checker	
Function Test	19-47
Wheel Sensor	
Signal Confirmation ..	19-49
Troubleshooting	
Anti-lock Brake System (ABS)	
Indicator Light	19-50
Symptom-to-System Chart	
'91-'92 Models	19-52
'93-'95 Models	19-52

Hydraulic System	
Index	19-76
Relieving Accumulator/	
Line Pressure	19-77
Modulator Unit	
Replacement	19-78
Index/Torque	19-80
Solenoid Leak Test	19-81
Pump Assembly	
Index/Torque	19-82
Accumulator Disposal ...	19-83
Bleeding	
Air Bleeding with ALB	
Checker	19-84
Electronic Components	
ABS Control Unit	
Replacement	19-85
Relays Inspection	19-85
Pulsers/Wheel Sensors	
Inspection	19-86
Wheel Sensor	
Replacement	19-87

TCS (Traction Control System)

Component Location Index ..	19-90
System Description	19-91
Outline	19-91
Construction and	
Function	19-92

Circuit Diagram	19-96
Troubleshooting	19-98
TCS Switch	19-152

Fail-Safe Relay	19-152b
Lateral Acceleration (Lg)	
Sensor	19-153b

TCS Control Unit	19-153
Steering Angle Sensor	
Replacement	19-154
TCS Control Valve	
Assembly	19-156