






Component Locations

Index



SERVICE CHECK CONNECTOR (2P)
Self-diagnostic Procedures, page 11-34

CLUTCH SWITCH (M/T)
Troubleshooting, page 11-94



M/T:
ENGINE CONTROL MODULE (ECM)
A/T:
POWERTRAIN CONTROL MODULE (PCM)
Self-diagnostic Procedures, page 11-34
Troubleshooting, page 11-26 ('91-'92 Models) and 11-42 ('93-'95 Models)

PGM-FI MAIN RELAY
Relay Testing, page 11-121
Troubleshooting, page 11-122

Component Locations

Index

