

Power Mirrors

Power Mirror Replacement

1. Carefully pry the cover panel out with a flat tip screwdriver.
2. Disconnect the 8-P connector from the mirror.
3. While holding the mirror with one hand, remove its mounting screws with the other.

