


Heater-Evaporator Door Adjustment

Mode Door Adjustment

Adjust the mode control motor rod as shown.



Air-mix Door Adjustment

Adjust the air-mix control motor rod as shown.

