


# Starting System

## Starter Overhaul (Mitsubishi type)

**CAUTION:** Disconnect the battery cable before removing the starter (see page 23-91).





## Starter Overhaul (Mitsuba type)

**CAUTION:** Disconnect the battery cable before removing the starter (see page 23-91).

