



Thank you for purchasing the convenient electronic drums from our company! This lightweight, stylish, simple portable electronic drum with modern technology and electronic industry innovative design, is the tireless efforts of all the results. This product has a very precise structure design, in order to avoid damage, the operation must be careful! For normal use and maintenance, please be sure to read the following methods of use and product operation, especially for young children, please use the product to do a detailed explanation. We wholeheartedly hope that it will give full play to your musical talent, to bring you very happy and wonderful music to enjoy.

I. Functions and features:

- A. The world's first, portable multi-function professional electronic drum with stereo sound;
- B. Light, stylish, simple and easy to carry;
- C. Built-in multi-group high-quality drum sound source, the most real and most shocking drums!
- D. The standard drum settings, pedal expansion interface to bring you the real shelf drum to enjoy.
- E. Comes with a professional demonstration song, to facilitate your appreciation, learning;
- F. With accompaniment, free to adjust the speed, is your best learning, practice partners;
- G. Comes with recording function, so you can record your music anytime, anywhere inspiration;
- H. MIDI output, can be connected to the computer playing electronic drum game;
- I. Comes with high-fidelity double horn external sound, easy to use anytime, anywhere;
- J. Audio input / output interface, a strong ability to expand, free to choose music songs to create music;
- K. Four power supply (A: USB5V B: three AA batteries C: BL-5C lithium battery D: power adapter power supply)

II. The appearance of structure:





IV. LED Lamp function description:

NO	Functions
16	Audio level display
17	Charging, recording light; charging, the red light, full of off, recording, the green light

V. Structure Function Description:

NO	Functions
18	Left speaker sound mouth
19	Right speaker sound mouth
20	battery box

VI. Hit area function description:

NO	Keys	Functions
PAD1	Crash Cymbal	Hanging cymbals (1)
PAD2	Open Close Hi-Hat	Open / phonetic hi-hat
PAD3	Snare Drum	Snare drums
PAD4	High Tom	Treble drums
PAD5	Bass Drum	Bottom drum
PAD6	Hi-Hat	Hi-hat
PAD7	Low Tom	Tone drums
PAD8	Floor Tom	Floor to drums
PAD9	Ride Cymbal	Cymbals or floating cymbals
PAD10	Crash Cymbal	Hanging cymbals (2)

VII. Common operating instructions :

1. Drum Kit: Press the STYLE key to select a different Drum Kit.
2. Play and select the demo song: press the DEMO button, you can play or in turn select a different demo song.
3. Play and select Style: Press the RHY key to play or select a different accompaniment in sequence.
4. Battery charging: When the sound becomes smaller or when the sound is unstable, that is, very little power, need to charge, at this time, you can use this cable with labels "POWER" to charge for the drum kit charging process, charging red light has been bright, full of electricity, the red light off.
5. Pedal Function Operation: Connect the double pedal plug to the foot pedal interface HI-HAT on the back of the loquax machine. You can use the foot pedal and the knock on the drum (Open Close Hi-Hat) to play different percussion sound. At the same time, you can through another foot, to achieve the drum knocking sound.
6. When connect with PC or cellphone ; please use the usb cable with label "MIDI" on it, and you also need an OTG cable to change it.

III. Product Features:

NO	Keys	Functions
1	ON/OFF	switch
2	USB	USB charging interface, connect the computer
3	Mp3	Mp3 audio input interface
4	HI-HAT	Hi-hat, bottom drum foot interface
5	PHONES	Headphone and audio output interface
6	V+	Volume up
7	V-	Volume down
8	DEMO	Press this key to select and play the demo song
9	START/STOP	Start, stop playing demo song, accompaniment
10	STYLE	Rotate the drum kit
11	T+	Speed up
12	T-	Speed down
13	REC	Start, stop recording
14	PLAY	Start playing the recording
15	RHY	Loop switch accompaniment

VIII. Maintenance:

1. Keyboard dirty, please use a soft, clean cloth wipe.
2. After use, please gently place the product in a dry place.
3. Do not use this product in hot and humid places.

VX. Precautions:

1. When placing, please pay attention to radio, TV and other strong electromagnetic products to keep the distance, so as to avoid interference.
2. Do not put heavy objects on the drum machine, to avoid the impact of collision, as not to damage.
3. Please do not press the electronic drum to 90 degrees or a large degree of folding, so as not to damage.
4. Please do not put sharp objects and the electronic drum co-storage or collision, so as not to damage.
5. Do not use or store this product in hot or humid environments.
6. When using, do not put this product on a rugged plane, otherwise the keyboard will not play properly.
7. Do not disassemble and drop this product.

X. Product is abnormal:

1. When the electronic drum generates an error, turn off the power, restart the machine, and restore to the original settings.
2. In the temperature or other rapidly changing environment, the drum may have abnormal performance. When this problem occurs, please spread the normal and smooth the keyboard, and then confirm the keyboard on each key function is normal.

XI. Packaging accessories:

Electronic drums*1	USB data cable*1	Manual*1
Drum sticks*2	BL-5C battery*1	

XII. Accessories area:

A: Double pedal B :Audio Line

XIII. Product specifications:

1. Dimension: 49*37*6.8 CM
2. Weight: 1068 g
3. Input voltage: USB 5V(Battery:AA*1.5V*3PCS)
4. Material: Silicone gel
5. Output voltage: 2*3W
6. Charging time: 2.5-3 hours
7. Working time: 3-4 hours