



Installing the AirSync App and Creating a New User Account

1. Install the AirSync App

The AirSync App is available exclusively for the iPhone and iPad. You can install the AirSync App from the Apple App Store at the following address.

www.air-sync.com/app


You can also search on the Apple App Store for “air-sync”

2. Create an AirSync Account

If you don't already have an AirSync account, you can create a new account by clicking “Create an Account” at the bottom of the screen when you open the AirSync App.

A screenshot of the AirSync app's login screen. At the top, the status bar shows the time 5:57, LTE signal, and battery level. The AirSync logo is centered, with the tagline "Your Aircraft. Always Connected." below it. There are three input fields: "Email", "Password", and a blue "Login" button. A link for "Forgot Password?" is located below the "Login" button. At the bottom, there is a link for "Create an account" and a horizontal line.

On the next screen enter the information requested.



6:05 LTE

< Back Create Account

First Name

Last Name

Mobile Number

Email

Password

Confirm Password

I have read and accept the [Terms of Service](#)

Submit

2. Login to your new AirSync Account

After you finish creating your account, you can login with your new account credentials.

If you are adding you are adding an aircraft to AirSync that is not managed by an AirSync operator, you will need to finish setting up your aircraft on the web at <http://service.air-sync.com>

If your aircraft is managed by an AirSync operator, let them know the email address you used to create your AirSync account and ask them to add the aircraft to your AirSync account.