Setup up for your iKeyboard 3mini controller section

1 — Logic Pro X | File | Edit | Track | Navigate | Record | Mix | View | Window | 1 | Hel

lesson1 - Tracks

About Logic Pro X

2 — Preferences ▶ | **3** — General...
Control Surfaces ▶ | Audio...
Key Commands ▶ | MIDI...
Display...
Download Additional Content... | Score...
Provide Logic Pro Feedback | Movie...
Download Logic Remote... | Automation... ⌥A
Learn About MainStage... | Advanced Tools...

Services ▶ | Initialize All Except Key Commands...

Preferences

General | Audio | MIDI | Display | Score | Movie | Automation | Control Surfaces | **Advanced** — **4**

☑ Show Advanced Tools
Enables advanced features, including: project alternatives and backups, beat mapping, expanded mixing and automation capabilities, additional editors and browsers, and more. Additional options become available and can be individually enabled.

Additional Options

☐ Audio
Enables destructive audio editing, and advanced configuration options for audio editing experts.

☐ Surround
Enables all features for surround audio productions, and requires a surround speaker setup for monitoring.

5 — ☑ MIDI
Allows signal flow control and real-time processing of MIDI input and output streams in the Environment.

6 — ☑ Control Surfaces
Allows experts to create new, and edit any functional detail of existing control surface systems.

---

7 — Logic Pro X | File | Edit | Track | Navigate | Record | Mix | View | Window | 1 | Help

lesson1 - Tracks

About Logic Pro X

Preferences ▶
8 — Control Surfaces ▶ | Learn Assignment for "no destination parameter"
Key Commands ▶ | Controller Assignments...

Download Additional Content... | **9** — Setup...
Provide Logic Pro Feedback | Preferences...
Download Logic Remote...
Learn About MainStage... | Rebuild Defaults
Bypass All Control Surfaces

Services ▶

Control Surface Setup

Edit ▾   New ▾   **10**

Install...   **11**
Scan All Models

✓ Automatic Installation

▼ Device:

▼ CS Group:

Flip Mode: Off
Display Mode: Value

Edit ▾   New ▾

▼ Device: No Device

▼ CS Group: Control Surface Group 1

Install

Manufacturer ▲	Model	Module
Korg	microKONTROL	microKONTROL
M-Audio	iControl	iControl
Mackie Designs	Baby HUI	HUI
Mackie Designs	HUI	HUI
Mackie Designs	HUI Channel Strips only	HUI
Mackie Designs	Logic Control	Logic Control
Mackie Designs	Logic Control XT	Logic Control
12 Mackie Designs	Mackie Control	Logic Control
Mackie Designs	Mackie Control C4	Logic Control
Mackie Designs	Mackie Control Extender	Logic Control
Radikal Technologies	SAC-2K	SAC-2K
Roland	SI-24	SI-24
Tascam	FE-8	FW-1884
Tascam	FW-1082	FW-1884
Tascam	FW-1884	FW-1884

13   Add   Scan

Control Surface Setup

Edit ▾   New ▾

▼ Device: Mackie Control

14   Output Port: iCON iKeyboard 3mini V1.01

15   Input Port: iCON iKeyboard 3mini V1.01

Module: Logic Control
Model: Mackie Control
Version: (unknown)
Color:

Transport Button Click: ☑
Touchless movable faders: ☐
Fader Touch Sensitivity: 3
Backlight Saver Timeout (min): 15

☐ Mackie Control