


# NOTEBOOK COMPUTER SKIN REFERENCE GUIDE

Thank you for purchasing this MANHATTAN® Notebook Computer Skin. These faux-animal, limited-edition designs are printed on durable material that's easily applied — and removed without any remaining residue — to help protect new computers from minor everyday hazards and refresh the look of those with minor scratches and abrasions. Fits most widescreen computers up to 15.4".

## ALSO AVAILABLE:



Zebra, Model 475761




Tiger, Model 423212

Shown: Cheetah,  
Model 475754  
with grid




1. Clean your notebook cover, letting the surface dry before applying the skin.



2. With the skin's grid (back) side facing up and using the notebook cover dimensions, trim the skin to fit. *TIP:* Some notebook covers feature beveled edges, rounded corners or other design characteristics that may affect full adhesion and a flat, secure installation. To compensate, consider trimming up to 2 cm (0.75 in.) more when preparing the skin for application.



3. Place the skin on the notebook cover to confirm that no additional trimming is needed, then peel away the back of the skin to expose the adhesive surface.



4. Carefully position the skin on your notebook cover — taking into account any edge features addressed above in Step 2 — and press it into place.

**SPECIFICATIONS** • Material: 70% acrylic / 30% polyester; paper base • Dimensions: 225 x 330 mm (8.8 x 13 in.) • Weight: 45.3 g (1.6 oz.)



# MANHATTAN™

BRINGING COMPUTERS TO LIFE

MANHATTAN® offers a complete line of PC Components, Peripherals, Cables and Accessories.  
Ask your local computer dealer for more information or visit us online at

[www.manhattan-products.com](http://www.manhattan-products.com)

Copyright © MANHATTAN

All products mentioned are trademarks or registered trademarks of their respective owners.