## UK 30-Bay AC Charging Cart

# :manhattan® Life just got easier. \*\*\*The control of the control o

## Instructions

Models 181174

Important: Read before use.



### For additional benefits

Scan to register your product warranty

or visit: register.manhattanproducts.com/r/181174





For specifications, please visit <u>manhattanproducts.com</u>.

Register your product at <u>register.manhattanproducts.com/r/181174</u> or scan the QR code on the cover.

#### Setup



1 Unlock unit door(s) and open them.



2 To fit a larger device, remove an appropriate slot divider. Push the divider to the back of the cabinet and lift it up. Replace a divider by placing it into the slot and pulling it toward you.



- 3 Connect devices to power outlets with appropriate cables. Secure cables with wire clips on dividers.
  - Connect power cables to power outlets, feeding cables through holes on back panel.
  - Load devices into the bays.
  - · Connect cables to devices.

#### Charging

- A Open the compartment and take the power cord
- **B** Connect the power cord to the unit and a power outlet
- C Push the button to turn on the power supply and start charging.







#### **WASTE ELECTRICAL & ELECTRONIC EQUIPMENT**

Disposal of Electric Equipment (applicable in the E.U. and other countries with separate collection systems)



This symbol on the product or its packaging means that this product must not be treated as unsorted household waste. In accordance with EU Directive 2012/19/EU on Waste Electrical and Electronic Equipment (WEEE), this electrical product must be disposed of in accordance with the user's local regulations for electrical or electronic waste. Please dispose of this product by returning it to your local point of sale or recycling pickup point in your municipality.

#### **WARRANTY AT**

manhattanproducts.com

#### **GENERAL PRODUCT SAFETY INSTRUCTIONS**

- This product is intended for indoor use only. Do not expose to rain, moisture, or excessive humidity.
- Keep away from heat sources, open flames, and direct sunlight.
- · Use the brakes on the casters to prevent unintentional rolling.
- Only use the included power cable or an equivalent rated C13 to AC plug cable.
- Do not use with daisy-chained power strips or extension cords.
- Unplug the cart from the mains before cleaning or performing any maintenance. Clean only with a dry or slightly damp cloth. Do not use chemicals, sprays, or water.
- Ensure the ventilation slots are not obstructed. Proper airflow is essential for cooling and safe operation.
- Regularly check power cables, locks, and casters for signs of wear or damage.

#### **REGULATORY STATEMENTS**

CE / UKCA

THIS device complies with the requirements of CE 2014/30/EU (UKCA Electromagnetic Compatibility Regulations 2016) and / or 2014/35/EU (UKCA Electrical Equipment [Safety] Regulations 2016). The Declaration of Conformity for is available at:

support.manhattanproducts.com/barcode/181174

POWER INFORMATION	
	181174
Input	220-240 VAC,
	50-60 Hz, 10.0 A
Power (max.)	2300.0 W









North & South America IC Intracom Americas 550 Commerce Blvd. Oldsmar, FL 34677, USA **Asia & Africa** IC Intracom Asia 4-F, No. 77, Sec. 1, Xintai 5th Rd. Xizhi Dist., New Taipei City 221, Taiwan Europe IC Intracom Europe Löhbacher Str. 7, D-58553 Halver, Germany

All trademarks and trade names are the property of their respective owners.

© IC Intracom. All rights reserved. Manhattan is a trademark of IC Intracom, registered in the U.S. and other countries.





manhattanproducts.com