

SUBJECT: Walking tractors with PowerSafe® clutch : MAINTENANCE

After the first 30 hours of use:

- Replace the external filter (B) with original item 58056208
- Check the fluid level using the gearbox dipstick (A), top-off if necessary.

Weekly:

- Check the fluid level using the gearbox dipstick (A), top-off if necessary.

Every 100 hours of use or once per year (whichever occurs first):

- Remove magnetic cap (C) and drain fluid
- Replace the external filter (B) with original item 58056208
- Clean and reinstall magnetic cap (C)
- Re-fill with fluid until the dipstick (A) measures the appropriate level

Compatible Universal Tractor Hydraulic/Transmission Fluid Specification Options:

- | | |
|---------------------------------|---|
| • VCE-WB 101 | • Case MS 1207, 1210 |
| • CAT TO-2 | • Ford ESN-M2C86-B, ESN M2C86-C, |
| • Allison C-4 | ESN-M2134-D |
| • John Deere JDM J 20C | • FNHA-2-C-201 |
| • MF M1135, M1141, M1143, M1145 | • ZF TE-ML 03E, 06K, 17E |
| • Kubota UDT Fluid | • Universal/Heavy Duty Tractor |
| • Case New Holland MAT 3525 | Hydraulic/Transmission Fluid at NAPA, TSC, etc. |

For Cold Weather Applications, use either of the following Synthetic Hydro Fluids:

- | | |
|-------------------|-------------------------|
| • Amsoil (ATH-05) | • Shell Spirax (S3 TLV) |
|-------------------|-------------------------|

