



# SERVICE INFORMATION

# 2-22

Revised 01/27/2016

**SUBJECT: Walking tractors with PowerSafe® clutch : MAINTENANCE**

After the first 30 hours of use:

- Replace the external filter (B) with original item 58056208
- Check the fluid level using the gearbox dipstick (A), top-off if necessary.

Weekly:

- Check the fluid level using the gearbox dipstick (A), top-off if necessary.

Every 100 hours of use or once per year (whichever occurs first):

- Remove magnetic cap (C) and drain fluid
- Replace the external filter (B) with original item 58056208
- Clean and reinstall magnetic cap (C)
- Re-fill with fluid until the dipstick (A) measures the appropriate level

### Compatible Universal Tractor Hydraulic/Transmission Fluid Specification Options:

- VCE-WB 101
- CAT TO-2
- Allison C-4
- John Deere JDM J 20C
- MF M1135, M1141, M1143, M1145
- Kubota UDT Fluid
- Case New Holland MAT 3525
- Case MS 1207, 1210
- Ford ESN-M2C86-B, ESN M2C86-C, ESN-M2134-D
- FNHA-2-C-201
- ZF TE-ML 03E, 06K, 17E
- Universal/Heavy Duty Tractor Hydraulic/Transmission Fluid at NAPA, TSC, etc.

### For Cold Weather Applications, use either of the following Synthetic Hydro Fluids:

- Amsoil (AHT-05)
- Shell Spirax (S3 TLV)

A: Dip Stick

B: Filter

C: Magnetic Cap  
(located on valve body opposite spin-on filter)

