

AMANA FURNITURE SHOP STANDARD QUARTZ CLOCK INSTRUCTIONS:

1. TO SET THE TIME:

- On the backside of the clock, the battery compartment and time adjustment wheel should be visible. Simply use the time adjustment wheel to set the correct time.

2. BATTERIES:

- Insert the battery according to the positive (+) and negative (-) markings in the battery compartment. **It is important to ALWAYS insert the positive (+) end first.**
- The movement type determines the battery size. These battery sizes should be readily available at most discount and home improvement stores.
- Oftentimes, the battery size is listed inside the battery compartment. However, if it is not and you are unsure about which size to use, please call 319-622-3291 or 1-800-247-5088 for our assistance.

3. WARRANTY:

- All Amana quartz movement clocks have a one (1) year warranty on the movement. If you have any additional questions about your Amana clock, once again please call 319-622-3291 or 1-800-247-5088. You may also e-mail us at furniture@amanafurniture.com