




# YARIS




3 DOOR

2014-7






	<b>IG/ENGINE SW</b>		<b>Fuse Box</b>		<b>12V Battery</b>
	<b>Airbag (incl. Inflator)</b>		<b>Inflator</b>		<b>Fuel Tank</b>
	<b>Gas-filled Damper</b>		<b>Seat Belt Pretensioner (Gas Generator)</b>		<b>Structural Reinforcements</b>
	<b>Airbag Computer</b>	—	—	—	—
—	—	—	—	—	—




### Disable Vehicle




or



### Access to 12V Battery






### Towing Information



# YARIS


5 DOOR

2014-7




	<b>IG/ENGINE SW</b>		<b>Fuse Box</b>		<b>12V Battery</b>
	<b>Airbag (incl. Inflator)</b>		<b>Inflator</b>		<b>Fuel Tank</b>
	<b>Gas-filled Damper</b>		<b>Seat Belt Pretensioner (Gas Generator)</b>		<b>Structural Reinforcements</b>
	<b>Airbag Computer</b>	—	—	—	—
—	—	—	—	—	—


### Disable Vehicle



or



### Access to 12V Battery



### Towing Information

