









Note: The Rescue Sheet depicts a LHD vehicle (as allowed under the ISO 17840-1). All components (other than steering wheel and passenger airbag) are located in the same position in the Aust/NZ RHD model.



Legende

	Airbag		Karosserie-verstärkung		Steuergerät		Gastank
	Gas-generator		Überroll-schutz		Batterie		Sicherheits-ventil
	Gurt-strafer		Gasdruck-dämpfer		Kraftstoff-tank		

