


LDV TERRON 9 PICK-UP,4 Doors 2024-10














	Airbag		Stored gas inflator		Seat belt pretensioner		SRS control unit		Zone requiring special attention
	High strength zone		Fuel tank	000 000	Battery low voltage	44	Gas strut/ Preloaded spring		
		ID No.			Version No.		Version date		Page
		LSK-SKK1-ICE-E001			01		10/2024		1 of 4




LDV TERRON 9

PICK-UP,4 Doors 2024-10






1. Identification / recognition




2. Immobilisation / stabilisation / lifting




3. Disable direct hazards / safety regulations

■ Main method










• Just press the button once, The vehicle will be in P. • Click the "power off "button .


• Disconnect 12 Volt battery


■ Access to 12V Battery





2







3

Pull the opening handle of the bonnet lock

• Disconnect 12 Volt battery

ID No.	Version No.	Version date	Page
LSK-SKK1-EV-E001	01	10/2024	2 of 4




LDV TERRON 9

PICK-UP,4 Doors 2024-10





4.Access to the occupants







Electric 1st row



Manual 1st row






Steering column adjustment



High strength body areas



5. Stored energy / liquids / gases / solids

80L
12V
R-134a 950g

ID No.	Version No.	Version date	Page
LSK-SKK1-ICE-E001	01	10/2024	3 of 4



LDV TERRON 9

PICK-UP,4 Doors 2024-10





6. In case of fire



USE LARGE AMOUNT OF WATER











7. In case of submersion





Work on the vehicle only after the vehicle has been pulled out of the water.

8. Towing / transportation / storage

On RWD models:

On AWD models:





9. Important additional information

■ Centre airbag



LSK-SKK1-ICE-E001


■ Maxus Guideline for Rescue Services:

10/2024

4 of 4

https://www. Maxus.com

10. Explanation of pictograms used



01