

Cisco Phone Provisioning Guide

SPA 50x

1. Power up the phone
2. Press the menu key (below the envelope button) then press option 9 to obtain the IP address of the phone.
NOTE: phone must be using DHCP, and your browser must be on the same network as the phone
3. Open web browser and type in IP of phone (<http://x.x.x.x>)
4. Select "Admin" login
5. Select "Advanced"
6. Click on "Provisioning" tab and set "Profile Rule" to:
[http://sipregistration.com/pbxcontext/spa\\$MA.xml](http://sipregistration.com/pbxcontext/spa$MA.xml)
7. Press "Submit All Changes" and the phone will reboot.