



Zoom H1 Instructions- Please share with person who is using

Your Zoom has been completely charged & tested before it was sent to you. But, we do recommend checking them after you receive them. If you run in to any issues call us or email us immediately.

ZOOM USER INSTRUCTIONS

Operate Recording

After turning on the unit, you can start recording from the home screen with the press of one button.



1. Press  to start recording.
 - The recording time appears on the screen.
2. Press  again to stop recording and return to the home screen.







MEMO


If no microSD card is in the unit, you can still record one file of up to 35 seconds using the unit's built-in memory. Be aware that recording again without a card will overwrite the recording already in the built-in memory.

Operate Play

Play back recorded audio.



- Press  to play the last recorded file.
- The remaining playback time appears on the screen.
- Main button functions during playback
 -  ... Press during playback to select files
 -  ... Press to pause/resume
 -  ... Press to return to the home screen



MEMO

Playback automatically stops after all files have been played.

Prepare Turning the power on/off


Turning the unit ON and OFF is easy.









1. To turn the unit ON, slide the power switch down for about 1 second.
2. To turn the unit OFF, slide the power switch down for about 1 second again.

Operate Delete

You can delete recorded audio files.



1. Press  during playback of the file that you want to delete.
2. Press  to confirm. Press , ,  or  to cancel deletion.

