

EnergyGauge USA 5.1.01

Release Notes

The latest release of EnergyGauge USA, Version 5.1.01 includes a few fixes to issues identified in 5.1.00 that impacted HERS Raters. To see the many changes that were included in 5.1.00 please see [the 5.1.00 release notes](#).

KEY FEATURES ADDED

None

IMPORTANT NOTE TO ALL** Loading files from EnergyGauge USA 5.0.03. This EnergyGauge USA 5.1.00 install will update the EnergyGaugeUSA5003 folders and install a new database. As a result, your projects will need to be loaded into 5.1.00. The bldgs folder which contains the Backup and Examples folders will remain in the EnergyGaugeUSA5003 folder and can be access under My Documents. For instance, if your username is **jsmith** and the EnergyGauge USA version is 5.0.03 the file location will be: c:\users\jsmith\Documents\EnergyGauge5.0.03. This is also the default folder location for the “**Load *.enb**” and “**Save *.enb**” options.

WINDOWS VERSIONS SUPPORTED

Minimum System Requirements: Windows Vista, Windows 7, Windows 8, Windows 8.1 or Windows 10.

GENERAL BUG FIXES

- Removed an extra combo box from the preferences site tab in all versions
- Removed the Files tab from preferences in all versions

FLORIDA CODE CHANGES AND OTHER FEATURES

- None

HERS RATERS FIXES

- The Infiltration Date and Time Selector button will now allow input after selecting the Clear Date button
- Hot water system recovery efficiency has been corrected for tankless gas DHW with an EF below 85% in the HERS Rater version
- Error no longer displays when creating an RGU file if the single point blower door method was used in Florida
- Removed a slab below grade perimeter warning when calculating check RESNET warning flags for homes with basements