


Vango

FOLDING GAS STOVE

Important: Read these instructions carefully and familiarise yourself with the stove before connecting it to its gas container. Keep these instructions for future reference. Gas consumption and heat input were measured and calculated in accordance with in-house testing methods.

SPECIFICATION:

Dimensions: Open: H:7 / W:Ø17.4cm. **Folded:** H:6 / W:Ø9cm. **Weight:** 220g (269g packed). **Power:** 8850 BTU (2600W). **Ignition:** None. **Gas cartridge:** This stove shall only be used with screw-top, butane-propane mixture cartridge that complies with EN417. It may be hazardous to attempt to fit other types of gas Cartridge.



USER INFORMATION:

1. Open the 3 pot supports, extended the 3 legs, placing on a flat, level surface.
2. **Attaching cartridge to stove:** Attach the gas cartridge to the valve on the stove, turning in a clockwise direction.
3. **Lighting the flame:** Turn the flame control slowly in an anti-clockwise direction and ignite using a match, lighter, etc.. If the stove does not light, shut the flame adjustment control completely off and start the lighting process over again from the beginning.
4. **Adjusting the flame:** Turn the flame control slowly in an anti-clockwise direction for a larger flame and clockwise for a smaller flame.
5. **Extinguishing the flame:** Turn the flame control slowly clockwise until it stops, and then check to make sure that the flame is completely extinguished. When replacing the gas cartridge, extinguish the flame and wait until the stove has cooled down sufficiently.
6. **Removing cartridge from stove:** Remove the gas cartridge from the valve on the stove, turning in an anti-clockwise direction.

CAUTION:

1. **USE ONLY IN A WELL VENTILATED AREA.**
2. Check the seals are in place and in good condition before connecting to the gas cartridge.
3. Do not use the stove if it has damaged or worn seals, if it is leaking, damaged or does not operate properly.
4. This stove is for outdoor use only. Never use it inside tents, in enclosed spaces, or inside vehicles. Due to the stove consuming large amounts of oxygen, its use in enclosed spaces may lead to carbon monoxide poisoning or fire. Therefore any use in an enclosed space would be extremely dangerous.
5. This stove must be operated on a flat, level surface.
6. Keep all combustibles at least 1 metre away from the top and 1 metre away from the sides of the stove.
7. Avoid twisting the flexible hose.
8. A small amount of gas may escape when attaching or detaching the gas cartridge. Therefore do not attach or detach the cartridge if there is a risk of fire or in a confined space with poor ventilation. Keep away from other people and any sources of ignition, such as naked flames.
9. If there is a leak on your stove (smell of gas), take it outside immediately into a well ventilated flame free location where the leak may be detected and stopped. If you wish to check for leaks on your stove, do it outside. Do not try to detect leaks using a flame, use soapy water.
10. Parts may become very hot. Keep young children away from the stove.
11. After use, inspect and clean the stove before storing it, to avoid problems when using it the next time.

VANGO WARRANTY POLICY:

All Vango products are designed and manufactured to exacting standards and are covered by our user warranty.

The warranty covers all manufacturing faults of the fabrics, parts and workmanship. This warranty* covers the functionality of the product for its normal, intended use as specified in the consumer literature or website. It does not cover a malfunction that has resulted from improper or unreasonable use or maintenance, accidents, damage due to excessive winds/weather, improper re-packing or natural degradation due to sunlight. The Vango Warranty lasts one year from the date of purchase**.

*For full details please see appropriate section on Vango website: www.vango.co.uk

**This may vary depending on the statutes in force within the country of purchase.

IF YOU ENCOUNTER ANY PROBLEMS PLEASE CONTACT YOUR LOCAL RETAILER or AMG Group Ltd., Kelburn Business Park, Part Glasgow, Scotland, PA1 4 6TD. UK Consumer Hotline: 0844 811 0535. Email: info@vango.co.uk

Calls to our Customer Hotline cost 5p per minute. Calls from mobile phones, cable networks or public payphones will generally cost more.

Vango makes every effort to ensure the accuracy of the information shown within this document, however we do pursue a policy of continuous improvement and we therefore reserve the right to change or amend information and specifications without prior notice.

