

# LG SmartTV Firmwareupgrade

## Main Firmware

The Main Firmware is shipped as .epk file and usually >700MB.

<b>Model</b>	<b>Firmware</b>
LY760H	<a href="#">LY760H-ZA-03.03.19_usb_V3_SECURED</a>
LY960H	<a href="#">LY960H-ZA-03.03.18_usb_V3_SECURED</a>
LX761H	<a href="#">starfish-dvb-secured-m14tvhotel-beehive4id-68-03.96.30-prodkey_usb_V3_SECURED</a>
UX960H	<a href="#">starfish-dvb-secured-lm15uhotel-beehive4id-6-03-00-10-prodkey_usb_v3_secured</a>

## Micom Firmware

The Micom FW is shipped as .HEX file, usually in the Size of <1 MB. The only way to apply this firmware is by local USB drive.

<b>Model</b>	<b>Firmware</b>
LY760H	<a href="#">Micom LY760H-ZA_V3.31_0x02F48A4D_20150903</a>
LY960H	<a href="#">Micom LY960H-ZA_V3.32_0x02F458E8_20150921</a>
LX761H	<a href="#">micom lx760h ux960h v3-26_0x02e46043_20151216</a>
UX960H	<a href="#">micom lx761h ux960h v3-20_0x02e50c00_2015030</a>

## ###Englisch

## USB Upgrade

### USB Upgrade Main Firmware

Prepare USB Stick

1. Format USB Stick with FAT 32
2. Create Folder \LG\_DTV\
3. Copy .epk file there

At the TV

1. Connect USB Stick to TV

2. Turn on TV
3. Autoupgrade is available (if higher version, if downgrade needed go to TV Manager and select update there)

## **USB Upgrade Micom Firmware**

Prepare USB Stick

1. Format USB Stick with FAT 32
2. Create Folder \LG\_DTV\
3. Copy .hex file there

At the TV

1. Disconnect USB Stick to TV
2. Turn on TV
3. Enter installation menu
  1. hold "Settings" on IR remote for 5 sec till you see the settings menu, still hold "Settings" until the menu disappears, now quickly do step 2.
  2. press on IR remote "1" "1" "0" "5" "ok"
  3. from Installation menu go to "TV Manager"
  4. Connect USB Stick to TV
  5. select "Update Micom Software"
  6. choose the file from USB and then choose update

## **#### French**

Vous trouverez ci-dessous la version du logiciel requise pour chaque modèle de téléviseur pour :

1. Main firmware
2. Micom Firmware

**Pensez à télécharger les fichiers avant de venir sur site**

## **USB Upgrade Main Firmware**

Préparation de la clé USB

1. Formatez la clé USB en FAT 32
2. Créez un dossier \LG\_DTV\
3. Copiez le fichier. epk dans le dossier

Sur le téléviseur

1. Connectez la clé USB au téléviseur
2. Allumez le téléviseur
3. Autoupgrade est disponible si la version de software est supérieure à la version software installée sur le téléviseur. (si on veut installer une version antérieure, allez dans TV Manager et sélectionnez update dans cette rubrique)

## **USB Upgrade Micom Firmware**

Préparation de la clé USB

1. Formatez la clé USB en FAT 32
2. Créez un dossier \LG\_DTV\
3. Copiez le fichier. hex dans le dossier

Sur le téléviseur

1. Déconnectez la clé USB du téléviseur
2. Allumez le téléviseur
3. Entrez dans le menu "Installation"
  1. Appuyez sur le bouton "Settings" de la télécommande jusqu'à ce que le menu apparaisse, restez toujours appuyer sur le bouton « Settings » jusqu'à ce que le menu disparaisse, maintenant passez rapidement à l'étape 2.
  2. Appuyez sur "1" "1" "0" "5" "ok"
  3. Dans le menu installation, choisissez "TV Manager"
  4. Connectez la clé USB au téléviseur
  5. Sélectionnez "Update Micom Software"
  6. Sélectionnez le fichier .hex sur la clé USB et appuyez sur « update »