

NEC System Time Change

- On any NEC Telephone
- Press **Speaker**
- Dial **8 2 8** on the Keypad
- Enter the time on the keypad as **HH MM** in 24 Hour Format
(for 9am you would enter 0900)
- Press **Hold**
- Press **Speaker**

*(Please note some customer systems may require a * before the 828 feature code)*