

# G120 Wiring Diagram For ASYNC Immobilisation



**G120**


Power 8-45V

Chassis GND

Ignition Input

Yellow  
(Output 1/Switched  
Ground)

Coil Negative  
-VE



**Automotive Relay**

To Starter Motor

To Vehicle +VE

**Relay:**

- Pin 30: Common
- Pin 85: Coil Negative
- Pin 86: Coil Positive
- Pin 87: Normally Open
- Pin 87a: Normally Closed

Relay set to immobilise on ASYNC  
message