

Teknatool International Limited

7D Dallan Place, Rosedale, Auckland, New Zealand
 Tel: +64 09 477 5600 Fax: +64 477 5601

Email: service@teknatool.com
 Website: www.teknatool.com



Frequently Asked Questions

Self-Start function on the NOVA Voyager DVR Drill Press

Date Raised: 18 January 2017

Safe practices should always be employed to ensure the Health and Safety of yourself, employees and customers (if applicable) Refer to product manuals, exploded drawings and our website if further assistance is required, or contact us on service@teknatool.com

Date Amended

There is a "Self-Start" function included on the NOVA Voyager DVR drill press to allow one-handed drilling operations. This function will automatically turn the motor on and off at pre-determined start depths.

The motor will start running at 0.29" / 7mm and stops once it returns to 0.24" / 6mm when the feature is turned on.

To turn on the Self-Start feature on the drill press:

Step No.	Description	Image
1.	<p>Press the <Menu/ Cancel> key to go into the menu screen and navigate to the "Self-start" option by turning the dial.</p> <p>Press the dial in to turn ON the "Self-Start option"</p>	

This "Self-Start" function has the following characteristics

1. After the feature is turned on, the **handle must be raised to the top of the quill stock before the first "Self-Start" can begin.**
2. If the user is in the menu while the machine is on idle, the self-start will not start the motor but it will turn the motor off if the machine is running with the quill is extended.
3. The default, **safety features including warning sounds and delay before the motor self-start is turned off.** This setting can be changed by following the menu path: **Menu > Configuration > Drill Settings > Sounds/Warnings.**

If the self-start feature is not starting the motor even though the feature is turned on, please check the followings:

1. **Is the handle raised to the top of the quill stock before the drilling operation?**
 - Raise the handle back up to the highest position
2. **Are you inside the menu?**
 - Exit out of the menu to active self-start