



### Refill Instructions for TK-Fine Vario L Pencil:



1. Remove the eraser holder (3) from the barrel (2) by firmly pulling the eraser holder (3) out.
2. Insert new Faber-Castell leads (4) into the back end of the barrel (2). Add no more than 5 leads. If more leads are used this may cause a jam.
3. Return the eraser holder (3) to the barrel (2) by firmly pushing the eraser holder (3) back into place.
4. To advance the lead, push down on the eraser holder (3) and begin writing.
5. To retract the lead, push down on the eraser holder (3) and hold it in place. Push the lead back into the front piece (1) while the eraser holder (3) is held in place.

**Refills** Eraser: #131596  
Lead degrees of hardness available: **0.35mm** B, HB, H, 2H  
**0.5mm** 2B, B, HB, F, H, 2H, 3H  
**0.7mm** 2B, B, HB, H, 2H  
**1.0mm** HB, B, 2B

**Note** The TK-Fine Vario L Pencil is available in 0.35mm, 0.5mm, 0.7mm and 1.0mm and comes equipped with (HB) lead.