



### Refill Instructions for Design Twist Pocket Pencil:



1. Remove the eraser cap (3) from the barrel (1) by pulling the cap (3) off gently.
2. Remove the eraser (2) from the barrel (1).
3. Add 1 to 2 new Faber-Castell **0.7mm** leads (4) into the back of the barrel (1). Add no more than 2 leads. If more leads are used this may cause a jam.
4. Return the eraser (2) to the barrel (1).
5. Return the cap (3) to the barrel (1).
6. To advance the lead, turn the cap (3) clockwise and begin writing.
7. To retract the lead, hold the barrel (1), turn the cap (3) clockwise and hold it in place. Push the lead back into barrel (1) while the cap (3) is held in place.

**Refills** Eraser: #182203  
Lead: **0.7mm** (B) #122298  
Other degrees of lead hardness also available (2B, HB, H, 2H)

**Note** The Twist Pocket Pencil comes equipped with **0.7mm** (B) standard lead.