



GRAF VON FABER-CASTELL

Refill Instructions for Graf von Faber-Castell Anello Rollerball Pen:



1. Remove the cap (1) from the barrel (3) by turning the barrel (3) counterclockwise.
2. Remove the front piece (2) by turning the barrel (3) counterclockwise.
3. Remove the used refill (4) from the barrel (3).
4. Insert a new Faber-Castell Rollerball Refill (4) into the barrel (3).
5. Return the front piece (2) to the barrel (3) by turning the barrel clockwise and begin writing.
6. When not in use, return the cap (1) to the barrel (3) by turning the barrel clockwise.

Refills Rollerball: #148730 Black, #148731 Blue
Fineliner: #148735 Black, #148736 Blue

Note The Classic Rollerball Pen comes equipped with a black rollerball refill.