




Refill Instructions for Design Ambition Rollerball Pen:



1. Remove the cap (1) from the barrel (3) by pulling it off gently.
2. Remove the front piece (2) by turning the barrel (3) counterclockwise.
3. Remove the used refill (4) from the barrel (3).
4. Insert a new Faber-Castell Rollerball Refill (4) into the barrel (3).
5. Return the front piece (2) to the barrel (3) by turning the barrel clockwise and begin writing.
6. When not in use, return the cap (1) to the barrel (3) by pushing it on to the barrel (3) gently until you hear it click closed.

Refills Rollerball: #148712 Black, #148797 Black 2pk on Blister Card, #148713 Blue
 Fineliner: #148735 Black, #148736 Blue

Note The Ambition Rollerball Pen comes equipped with a black rollerball refill.