



Refill Instructions for GRIP 2011 Pencil:



1. Remove the eraser cap (4) from the barrel (2) by gently pulling the cap (4) off gently.
2. Remove the eraser holder (3) from the barrel (2) by firmly pulling the eraser holder (3) out.
3. Insert new Faber-Castell **0.7mm** leads (5) into the back end of the barrel (2). Add no more than 5 leads. If more leads are used this may cause a jam.
4. Return the eraser holder (3) to the barrel (2) by firmly pushing the eraser holder (3) back into place.
5. Return the eraser cap (4) to the barrel (2) by firmly pushing the eraser cap (4) back into place.
6. To advance the lead, push down on the eraser cap (4) and begin writing.
7. To retract the lead, push down on the eraser cap (4) and hold it in place. Push the lead back into the front piece (1) while the eraser cap (4) is held in place.

Refills Eraser: #131597
Lead: **0.7mm** (B) Standard #122298
Other degrees of lead hardness also available (2B, HB, H, 2H)

Note The GRIP 2011 Pencil comes equipped with **0.7mm** (B) standard lead.