


## How to Set GPS Time

Menu (Default password 6666)

System




Setup



## GPS



## Set to UTC 0



You can also set DST in

Base

DST

