



### Refill Instructions for Design Conic Ballpoint Pen:



1. Remove the front piece (1) from the barrel (2) by turning the barrel (2) counterclockwise.
2. Remove the empty ballpoint refill (4) from the front piece (1).
3. Insert new Faber-Castell Ballpoint Refill (4) into the front piece (1).
4. Return the front piece (1) to the barrel (2) by turning the barrel (2) clockwise.
5. Click the push button (3) to advance the ballpoint (4) and begin writing.
6. To retract the ballpoint (4) click the push button (3).

**Refills** Ballpoint: #148780 Fine, Black  
#148789 Medium, Black  
#148788 Medium, Blue  
#148742 Broad, Black  
#148743 Broad, Blue  
#148794 Extra Broad, Black  
#148793 Extra Broad, Blue

**Note** The Conic Ballpoint Pen comes equipped with a medium blue ballpoint refill.