



Refill Instructions for Grip 2010 and 2011 Pencils:



1. Remove the eraser cap (4) from the barrel (2) by gently pulling the cap (4) off gently.
2. Remove the eraser holder (3) from the barrel (2) by firmly pulling the eraser holder (3) out.
3. Insert new Faber-Castell leads (5) (**0.5mm** for **Grip 2010**; **0.7mm** for **Grip 2011**) into the back end of the barrel (2).
Add no more than 5 leads. If more leads are used this may cause a jam.
4. Return the eraser holder (3) to the barrel (2) by firmly pushing the eraser holder (3) back into place.
5. Return the eraser cap (4) to the barrel (2) by firmly pushing the eraser cap (4) back into place.
6. To advance the lead, push down on the eraser cap (4) and begin writing.
7. To retract the lead, push down on the eraser cap (4) and hold it in place. Push the lead back into the front piece (1) while the eraser cap (4) is held in place.

Refills Eraser: #131597 on Blister Card
 Lead: **Grip 2010 - 0.5mm** (B) Standard #120501
 Other degrees of lead hardness also available (2B, HB, H, 2H, F)
Grip 2011 - 0.7mm (B) Standard #122298 1pk on Blister Card
 Other degrees of lead hardness also available (2B, HB, H, 2H)

Note The Grip 2010 Pencil comes equipped with **0.5mm** (B) standard lead
 The Grip 2011 Pencils comes equipped with **0.7mm** (B) standard lead.