



GRAF VON FABER-CASTELL

Refill Instructions for Graf von Faber-Castell Slim Ballpoint Pen:



1. Remove the front piece (1) from the barrel (2) by turning the barrel (2) counterclockwise.
2. Remove the empty ballpoint refill (4) from the barrel (2).
3. Insert a new Faber-Castell Ballpoint Refill (4) into the barrel (2).
4. Return the front piece (1) to the barrel (2) by turning the barrel (2) clockwise.
5. Hold the barrel (2) and turn the cap (3) clockwise to advance the ballpoint (4) and begin writing.
6. To retract the ballpoint (4), hold the barrel (2) and turn the cap (3) counterclockwise.

Refills Ballpoint: **Broad**
#148742 Black
#148743 Blue
Extra Broad
#148794 Black
#148793 Blue
Medium
#148789 Black
#148741 Blue
Fine
#148780 Black

Note The Slim Ballpoint Pen comes equipped with a broad black refill.