




GRAF VON FABER-CASTELL

Refill Instructions for Graf von Faber-Castell Anello Ballpoint Pen:



1. Remove the front piece (1) from the barrel (2) by turning the barrel (2) counterclockwise.
2. Remove the empty ballpoint refill (4) from the barrel (2).
3. Insert new Faber-Castell Ballpoint Refill (4) into the barrel (2).
4. Return the front piece (1) making sure the spring is centered and the tip of the refill (4) slides into the middle of the spring inside the front piece.
5. Secure the front piece (1) by turning the barrel (2) clockwise.
6. Hold the barrel (2) and turn the cap (3) clockwise to advance the ballpoint (4) and begin writing.
7. To retract the ballpoint (4) hold the barrel (2) and turn the cap (3) counterclockwise.

Refills Ballpoint: **Broad**
 #148742 Black
 #148743 Blue
 Extra Broad
 #148794 Black
 #148793 Blue
 Medium
 #148789 Black
 #148741 Blue
 Fine
 #148780 Black

Note The Anello Ballpoint Pen comes equipped with a broad black ballpoint refill.