












ASSEMBLY INSTRUCTIONS

**ATTENTION: THIS PRODUCT IS NOT FOR COMMERCIAL USE
INTENDED FOR RESIDENTIAL USE ONLY.**

TGS39LA

PARTS LIST


PART NO.	MATERIAL CODE	PART	Q'TY				
1	TGS39LA-CS01	 TABLE TOP	1	6	17FA05040301-Y4	 WASHER d6.5*D13*1.0	8
2	TMS39LA-CS02	 LEG	2	7	18000337002	 BOLT CAP M6	8
3	62TMS39LAQ101	 SUPPORT	2	8	18000337007	 BOLT CAP M6	6
4	17C01A0701001Y7	 BOLT M6*8	6	9	17KAA0301----Y4	 HEX.KEY WRENCH 5MM	1
5	17C01A0706002Y4	 BOLT M6*16	8	10	17KAA0201----Y4	 HEX.KEY WRENCH 6MM	1
				11	1422	 TOUCH UP PAINT	1

Step 1:

Place the table top (#1) onto a non-abrasive surface, such as a carpet, with its underside facing upwards. Fasten the legs (#2) to the underside of the table top (#1) rim by using bolts (#4). Keep the bolts loose. See Figure 1.

Note:

The arrow marks on the legs (#2) must coincide with Figure 1 to ensure proper assembly.









-  Use the correct bolts as indicated. Do not tighten any of the bolts until the table is completely assembled.
-  Do not sit or stand on this table.
-  Do not discard of any of the packaging until you have checked that you have all of the parts and fittings required.
-  Keep children away during assembly. This item contains small parts that can be swallowed by children.
Children should always be under direct adult supervision while using this product.
-  Retain these assembly instructions for future reference.

FIGURE 2




Step 2:
Fasten the supports (#3) to the legs (#2) by using bolts (#5) and washers (#6). Keep the bolts loose. See Figure 2.

Note:

1. The arrow marks on the supports (#3) should coincide with Figure 2 to ensure proper assembly.
2. The tabs on the supports (#3) should be facing towards the inside to ensure proper assembly.

FIGURE 3



Step 3:
Fasten the supports (#3) to the underside of the table top (#1) rim by using bolts (#4). Make sure that all of the bolts have been tightened completely and cover them with bolt caps (#7 and #8). See Figure 3.

FIGURE 4



Step 4:
Turn the table to its upright position. See Figure 4.

Note:

To repair any scratches on the frame, use the touch-up paint (#11) provided.

Cleaning and Maintenance

- Wash frame parts with mild soap and water, rinse thoroughly, and dry completely. Do not use bleach, acid, or other solvents on the frame parts.
- Wash glass with mild soap and water, rinse thoroughly, and dry completely.
- Inspect and tighten all bolts and fasteners on a regular basis to ensure the proper performance and safety of your table.
- When moving the table, lift. Do not drag this table.
- We recommend the use of furniture covers when not in use.
- In order to prolong the life and beauty of your table, we recommend that it be stored in a dry and protected area during off season periods.