



# SPARE PARTS MANUAL

ETG 5000

**ELENOS**<sup>®</sup>  
World Broadcast Experience

# index

<b>E5KPZ004</b>	Low pass filter - (A1).....	7
<b>2PCB0521</b>	PCB combiner - (A2).....	7
<b>2RAF1017</b>	Unbalancing Resistor 500W 100 Ohm - (A3).....	7
<b>TG5KPZ900*</b>	RF Amp Output stage - "This code is without MOSFET" - (A4).....	7
<b>2CFCF302</b>	3000pF 25A capacitor - (A5).....	7
<b>TG2URPZ900*</b>	RF Amp input stage - "This code is without MOSFET" - (A6).....	7
<b>TG5K0A889</b>	Spiltter board - (A7).....	8
<b>9MOD4061</b>	Gap pad thermal probe - (A8).....	8
<b>9MOD4059</b>	Mechanical accessory for RF power MOSFET assembly - (A9).....	8
<b>9MOD2949</b>	Mosfet clamp - (A10).....	8
<b>2QRF0026</b>	Power MOSFET BLF578 - (A11).....	8
<b>2QRF0016</b>	Driver MOSFET BLF245 - (C9).....	8
<b>E3K 3B044R</b>	Switching power supply for driver - (B1).....	9
<b>EPSU3KWPZ001</b>	Switching power supply 3KW - (B2).....	9
<b>TG5K1A880R</b>	Acquisition board - (B3).....	9
<b>E3K 3A044R</b>	Switching power supply for fans - (B4).....	9
<b>TG5K3A881</b>	CPU-PSU connection board - (C1).....	9
<b>TG2UDA890</b>	VCO board - (C2).....	9
<b>TG5K4A881*</b>	Driver board - "This code is without MOSFET" - (C3).....	10
<b>TG2U0A899</b>	CPU board - (C4).....	10
<b>TG2U1A899</b>	TC/TS board - (C5).....	10
<b>TG2U2A899</b>	Channel board - (C6).....	10

<b>TG3K0B866R</b>	
Stereo Coder board - (C7) .....	10
<b>TG3K1A866R</b>	
Stereo inputs - (C8) .....	10
<b>TG3K2A867R</b>	
Stereo + AES/EBU inputs - (C8) .....	11
<b>1VENT026</b>	
Fan 120x120x38 12-28Vdc 306 m <sup>3</sup> /h - (D1) .....	11
<b>2DYL0012</b>	
Display oled 3,2" 256x64 - (D2) .....	11
<b>TG5K2A881R</b>	
Panel board - (D3) .....	11
<b>XNK PZ001</b>	
Oled Display adapter - (D3) .....	11
<b>TG5KPZ004</b>	
Front panel group - (D4) .....	11
<b>TG5KPZ200</b>	
E.Box kit (option) .....	12
<b>XNK 9A451</b>	
No mains board (option) .....	12
<b>1BAT0005</b>	
Battery (option) .....	12
<b>INT 0A940</b>	
Internet board (option) .....	12

### Spare parts placement

Please, look at the tables to find the placement of the spare parts inside the equipment.



All the spare parts listed (boards depending on version included) are referenced in the tables.

### Revision


N° Date Description

**Rev. 1.0** / Febbraio 2013 / First release

# ETG 5000 (A)



A8




A10


A9

A11


# ETG 5000 (B)



# ETG 5000 (C)



# ETG 5000 (D)



# Spare parts list model ETG 5000




## E5KPZ004

Low pass filter

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	A1	-



## 2PCB0521

PCB combiner

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	A2	-




## 2RAF1017

Unbalancing Resistor 500W 100 Ohm

Compatibility

Model	Quantity	Position	Price
ETG 5000	6	A3	-



## TG5KPZ900\*

RF Amp Output stage - "This code is without MOSFET"

Compatibility

Model	Quantity	Position	Price
ETG 5000	7	A4	-



## 2CFCF302

3000pF 25A capacitor

Compatibility

Model	Quantity	Position	Price
ETG 5000	7	A5	-



## TG2URPZ900\*

RF Amp input stage - "This code is without MOSFET"

Compatibility

Model	Quantity	Position	Price
ETG 5000	7	A6	-



## TG5K0A889

Spiltter board

Compatibility

Model	Quantity	Position	Prezzo
ETG 5000	1	A7	-



## 9MOD4061

Gap pad thermal probe

Compatibility

Model	Quantity	Position	Price
ETG 5000	7	A8	-



## 9MOD4059

Mechanical accessory for RF power MOSFET assembly

Compatibility

Model	Quantity	Position	Price
ETG 5000	7	A9	-



## 9MOD2949

Mosfet clamp

Compatibility

Model	Quantity	Position	Price
ETG 5000	7	A10	-



## 2QRF0026

Power MOSFET BLF578

Compatibility

Model	Quantity	Position	Price
ETG 5000	7	A11	-



## 2QRF0016

Driver MOSFET BLF245

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	C9	-





## E3K 3B044R

Switching power supply for driver

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>B1</b>	-



## EPSU3KWPZ001

Switching power supply 3KW

Compatibility

Model	Quantity	Position	Price
ETG 5000	3	<b>B2</b>	-



## TG5K1A880R

Acquisition board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>B3</b>	-



## E3K 3A044R

Switching power supply for fans

Compatibility

Model	Quantity	Position	Price
ETG 5000	2	<b>B4</b>	-



## TG5K3A881

CPU-PSU connection board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>C1</b>	-



## TG2UDA890

VCO board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>C2</b>	-



### TG5K4A881\*

Driver board - "This code is without MOSFET"

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	C3	-



### TG2U0A899

CPU board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	C4	-



### TG2U1A899

TC/TS board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	C5	-



### TG2U2A899

Channel board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	C6	-



### TG3K0B866R

Stereo Coder board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	C7	-



### TG3K1A866R

Stereo inputs

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	C8	-



## TG3K2A867R

Stereo + AES/EBU inputs

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>C8</b>	-




## 1VENT026

Fan 120x120x38 12-28Vdc 306 m<sup>3</sup>/h

Compatibility

Model	Quantity	Position	Price
ETG 5000	6	<b>D1</b>	-



## 2DYL0012

Display oled 3,2" 256x64

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>D2</b>	-



## TG5K2A881R

Panel board

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>D3</b>	-



## XNK PZ001

Oled Display adapter

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>D3</b>	-



## TG5KPZ004

Front panel group

Compatibility

Model	Quantity	Position	Price
ETG 5000	1	<b>D4</b>	-



### TG5KPZ200

E.Box kit (option)

Compatibility

Model	Quantity	Position	Price
ETG 5000	1		-



### XNK 9A451

No mains board (option)

Compatibility

Model	Quantity	Position	Price
ETG 5000	1		-



### 1BAT0005

Battery (option)

Compatibility

Model	Quantity	Position	Price
ETG 5000	1		-



### INT 0A940

Internet board (option)

Compatibility

Model	Quantity	Position	Price
ETG 5000	1		-


\* We strongly advise against making this change on their own. Due to complexity and criticality of the installation should be repaired in Elenos

#### Spare parts KIT

BUY ONLINE SPARE PARTS FOR "ETG 5000"


Visit our online shop, buy online and get your discount on single spare parts and spare part kits.

**BUY ONLINE, GO ON AIR!**



**SPARE PARTS  
FM TRANSMITTER KIT**

Surf our online shop,  
find special deals and buy spare part kits.  
You can save a lot of money, it's easy!



Scan with your phone


[shop.elenos.com](http://shop.elenos.com)

**ELENOS**  
SHOP





powe paktelhy:uz2lyhg2tblng . c o8P ARS PARET SARETOS 6R06 5000BEV . R EDV . 1. 00d . CMAN11000R025RVK



Elenos S.r.l.

[info@elenos.com](mailto:info@elenos.com) / [www.elenos.com](http://www.elenos.com)

**Elenos**  
**Elenos USA**  
**Elenos APAC**

**Via G. Amendola 9 / 44028 Poggio Renatico Ferrara (Italy) / Ph +39 0532 829965**  
1315 NW 98th Ct. Suite 9 / 33172, Miami (Florida) / Ph 1-855-ELENOS-0 (1-855-353-6670)  
53/64 Saracha Villa, Sansuk / Muang Chonburi, Thailand / Ph +66 83 618-9333