




What to do when the system is in alarm?

Instructions

1. Press on the “**status**” button 
2. Go to the sensor in alarm location
3. Stop the water leak & dry the sensor
4. Press the “**Reset**” button 
5. Press the “**Open valve**” button 

If step 5 does not work, follow the manual override procedure



Manual Override

1. Go to the valve location
2. Locate the white wheel and lift it
3. Turn the wheel clockwise until the valve is in the open position (do not push the wheel back)

If the valve begins to rotate on its own, let it complete its rotation and repeat step 3

4. Make sure there is no water leak in your home
5. Once the problem is resolved, push the wheel back to its original position to put the valve back into operation



WARNING



**Manual override compromises the proper functioning of the Nowa 360 system
Nowa and the installer cannot be held responsible for any damage resulting from
manual opening of the valve**

**It is your sole responsibility to make sure that there is no water leak and that it is safe
to open the valve**

Technical assistance

www.nowasupport.com / support@nowa360.com / [1-877-287-7777](tel:1-877-287-7777)