

# How to adjust the sound level of the control panel

## How to reduce the sound volume to the maximum

1. Press the following buttons in that order to quickly decrease the sound volume to maximum



## How to increase the sound level to the maximum

1. Press the following buttons in that order to quickly increase the sound volume to the maximum



## How to moderate the sound level

1. Press the following buttons to quickly moderate the sound volume



## Technical support

[www.nowasupport.com](http://www.nowasupport.com) / [support@nowa360.com](mailto:support@nowa360.com) / [1-877-287-7777](tel:1-877-287-7777)