








How to open the Nowa valve following a water leak detection?

Panel connected to the Internet

1. Press on the « **Status** » button 
2. Head to the sensor in alarm
3. Inspect the source of the problem - dry the sensor
4. If the check is green, it means that the sensor is dry. You continue to the next step.
5. Press on the « **Reset** » button 
6. Press on the « **Open Valve** » button 

Panel that lost it's date and time

7. Press on the « **Status** » button 
8. Head to the sensor in alarm
1. Inspect the source of the problem - dry the sensor
2. If the check  is green, it means that the sensor is dry. You continue to the next step.
3. Enter your user code
(Default : **1,2,3,4, enter**)
4. Press on the « **Open Valve** » button 


STATUS Press the status button to get more details about the state of the system.
Green The system is normal.
Yellow A sensor detects water, but the alarm has been cancelled .
Red A sensor is alarmed and/or a disorder is present . A disorder such as "loss of date and time" may remain present even if the water leak alarm has been cancelled . Only when all the troubles are corrected that the status button will go green again

