


Convergence Tuning


High Power Tuner

Remove all jumpers except S1



Slim Tuner

Remove all jumpers except S2



There is no S1 on the Slim Tuner

Turn on the reader and check the tuning indicator.



OUT, take jumper out



IN leave jumper in



OK antenna is in tune

Repeat for S2 through S7, one at a time.

Finish with the fine tuning adjustment to turn IN (clockwise) or OUT (counterclockwise)

The neon bulb should flash brightly when the antenna is in tune.