



Pitching Instructions – Icarus 500 & 600 Canopy

Pitching Instructions

- Assemble the poles & insert into pole sleeves on outside of canopy.
- Locate one end of the poles in ring & pin system as Figure 1 below.
- Push poles into an arch from opposite side and locate other pole end on to corresponding pin system on flysheet.
- Tension the webbing strap at the pole end.
- Position the open end of canopy towards tent.
- Secure in position by attaching the top webbing strap pole clips of the canopy to the second pole sleeve of the tent.
- Peg out canopy base at contact point with tent and then front of canopy to tension material.
- Secure in position by pegging out the guy lines.
- Peg out ALL peg points including rings as figure 2, and peg out ALL guy lines.

The Vango Icarus Canopy is designed for use in lowland sheltered campsites. Do not pitch in high winds or exposed campsites.



Figure 1.




Figure 2.