



Pitching Instructions – Loire 400 Front Canopy

Pitching Instructions

- Assemble the poles and insert into pole sleeves.
- Locate one end of the poles in Ring & Pin system as Figure 1 below.
- Push poles into an arch from opposite side and locate other pole end on to corresponding Ring & Pin system on flysheet.
- Tension the webbing strap at the pole end.
- Position open end of canopy towards tent front door.
- Secure in position by clipping the canopy roof webbing straps onto the second tent pole sleeve.
- Peg out canopy base at contact point with tent and attach rear side canopy clips to front tent pole.
- Peg out front of canopy and front guylines.
- Peg out ALL remaining guylines and peg points as figure 2.

The Vango Loire Front Canopy is designed for use in lowland sheltered campsites. Do not pitch in high winds or exposed campsites.




Figure 1.




Figure 2.