



Pitching Instructions – Zeya DLX 500 Front Canopy

Pitching Instructions

- Assemble the poles and insert into pole sleeves.
- Locate one end of the poles in Ring & Pin system as Figure 1 below.
- Push poles into an arch from opposite side and locate other pole end on to corresponding Ring & Pin system on flysheet.
- Tension the webbing strap at the pole end.
- Position open end of canopy towards tent front door.
- Secure in position by zipping canopy onto corresponding zip at front of tent and clipping the rear canopy clips onto the front tent pole.
- Peg out canopy base at contact point with tent and then front of canopy to tension material.
- Secure in position by pegging out front guy lines.
- Peg out ALL remaining peg points as figure 2.

The Vango Zeya DLX Front Canopy is designed for use in lowland sheltered campsites. Do not pitch in high winds or exposed campsites.



Figure 1.




Figure 2.